

Montageanleitung

Fitment Instruction

Bremslicht für Contour Hardtops und Camper

Brake Light for Contour Canopy and Camper

DE

1. An der oberen Rückseite im Inneren des Canopy findest du eine Abdeckplatte. Diese ist mit 4,8 mm x 10 mm großen Nieten befestigt. Bohre die Nieten vorsichtig aus und entferne die Abdeckplatte.
2. Öffne bzw. trenne die Kabelverbindung der Bremsleuchte. Sobald das Kabel getrennt ist, kannst du die alte Bremsleuchte entfernen.
3. Klebe die mitgelieferte Dichtung auf die neue Bremsleuchte. Führe das Kabel durch die Rückseite des Canopys und befestige die neue Leuchte.
4. Schiebe ein Stück Schrumpfschlauch über das Kabel, verbinde die Kabel wieder miteinander und schrumpfe den Schlauch, um die Verbindung zu isolieren.
5. Zum Schluss befestige die Abdeckplatte wieder mit schwarzen 4,8 mm x 10 mm Nieten.

ENG

1. On the rear top frame inside the canopy, locate the cover plate. It is secured with 4.8mm x 10mm rivets. Drill these rivets out to remove the cover plate.
2. Then, open or disconnect the brake light cable connection. Once it's disconnected, you can remove the brake light.
3. Apply the supplied gasket to the new brake light. Feed the cable back through the rear of the canopy and mount the brake light securely.
4. Add a piece of heat shrink tubing, reconnect the cable, and shrink the tubing to insulate the connection.
5. Finally, reattach the cover plate using black 4.8mm x 10mm rivets.